



BERG FURNITURE, INC.

120 E. Gloucester Pike Barrington, NJ 08007

ITEM NO. 67-42-XX

ASSEMBLY INSTRUCTIONS FOR THE FOLLOWING CRIBS: 65-381, 73-381, 73-424, 73-43, 74-381

Important: Read All Instructions Before Assembling. Please Save Instructions For Future Use


WARNING!

- * PACKAGING MATERIAL, SMALL PARTS & PLASTIC BAGS ARE HAZARDOUS TO SMALL CHILDREN. PLEASE DISPOSE OF THEM IMMEDIATELY!
- * IF YOU ARE MISSING HARDWARE OR HAVE ANY QUESTIONS, PLEASE CONTACT YOUR DEALER. DO NOT SUBSTITUTE PARTS! WE WILL GLADLY SEND YOU ANY HARDWARE YOU REQUIRE AT NO CHARGE.



MAIN DIAGRAM

HARDWARE



8 x MACHINERY SCREWS AND WING NUTS
(MAY BE ATTACHED TO MATTRESS SUPPORT)

12 x 2 3/4" ALLEN HEAD BOLTS

4 x BARREL NUTS

1 x ALLEN KEY

DIAGRAM 1




DIAGRAM 2





DIAGRAM 3



STEP 1: Adjust the height of the mattress support by connecting the 4 scissors using 4 sets of machine screws and wing nuts to the correct location (for a newborn, adjust it at the highest position as shown.) See Diagrams 1, 2 and 3.

DIAGRAM 4





DIAGRAM 5



STEP 2: Connect the stabilizer to the scissors using 4 sets of machine screws and wing nuts. See Diagram 4 and 5.

DIAGRAM 6





DIAGRAM 7



DIAGRAM 8




STEP 3: Connect the two sides of the crib to the stabilizers using 4 x barrel nuts and 4 x 2 3/4" Allen bolts. See Diagrams 6, 7 and 8.

DIAGRAM 9



DIAGRAM 10



MAIN DIAGRAM




STEP 4: Connect headboard to the sides using 4 x 2 3/4" bolts (See diagrams 9 & 10)

STEP 5: Connect Foot Board to the side rail using 4 x 2 3/4" bolts (same as in step #4) See Main Diagram.

CONVERTING THE CRIB INTO A DAY BED

GUARD RAIL HARDWARE




1 X ALLEN KEY

3 X 3 X 1-1/2" ALLEN BOLTS

DIAGRAM 11



DIAGRAM 12




STEP 1: Remove the Foot Board by releasing the 4 x 2 3/4" bolts. Please store the hardware in a safe place, out of reach of children. Do not store the foot board in an attic or any other place with extreme temperatures/humidity.

STEP 2: Lower the mattress support to the lowest position (See Diagram 11)

STEP 3: Using 3 x 1-1/2" Allen bolts, connect guard rail to the crib (See Diagram 11 & 12) Please Note: Do Not Over tighten.

CONVERTING THE CRIB INTO A FULL SIZE BED

CONVERSION HARDWARE



8 X 8 X 1-1/4" WOOD SCREWS

8 X LOCKING BOLTS

8 X CAM LOCKS

1 X ALLEN KEY

STEP 1: Remove the headboard and footboard away from the sides.

STEP 2: Prepare the headboard and footboard by inserting 4 x locking bolts into the bushings on the headboard and 4 x locking bolts into the footboard. (See Diagram #13)

STEP 3: Prepare the bed rails by inserting the maxi-cam lock into the 2 predrilled holes on each side of the rail.

Please Note: The arrow on the cam lock should face upward with the arrow pointing towards the hole at the end of the bed rail (See Diagram 14).

DIAGRAM 13




DIAGRAM 14




DIAGRAM 15



STEP 4: Connect the 2 bed rails to the headboard and lock it into its place by turning the cam lock clockwise. (See Diagrams 15 & 16).

Please Note: Do not over tighten.

DIAGRAM 16




DIAGRAM 17



DIAGRAM 18



STEP 5: Using two (2) people, connect simultaneously the other end of the bed rails into the footboard. (See Diagram 17).

STEP 6: Secure the headboard and footboard to the rails by tightening each of the 8 x cam locks (while slightly shaking the headboard and footboard). The arrow on the cam lock will point away from the headboard and footboard. (See Diagram 16).

DIAGRAM 19




DIAGRAM 20



STEP 7: Space the 4 x slats evenly and attach on both sides to the bed rail, using 8 x 1-1/4" wood screws. (See Diagrams 18 & 19)

Please Note: The slats need to sit tightly between the bedrails—make sure there is no extra space between them. (See Diagrams 19 & 20)

WARNING

FAILURE TO FOLLOW THESE WARNINGS AND ASSEMBLY DIRECTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

- READ ALL INSTRUCTIONS BEFORE ASSEMBLING CRIB. KEEP INSTRUCTIONS FOR FUTURE USE.
- BEFORE EACH USAGE OR ASSEMBLY, INSPECT CRIB FOR DAMAGED HARDWARE, LOOSE JOINTS, MISSING PARTS OR SHARP EDGES. DO NOT USE CRIB IF ANY PARTS ARE MISSING OR BROKEN. ASK YOUR DEALER OR WRITE TO (MANUFACTURER) FOR REPLACEMENT PARTS AND INSTRUCTIONAL LITERATURE IF NEEDED. DO NOT SUBSTITUTE PARTS.
- AFTER RAISING SIDE, MAKE SURE LATCHES ARE SECURE. **(NOT APPLICABLE)**
- WHEN CHILD IS ABLE TO CLIMB OUT OR REACHES THE HEIGHT OF 35 IN., THE CRIB SHALL NO LONGER BE USED AS A CRIB.
- DO NOT PLACE CRIB NEAR WINDOW WHERE CORDS FROM BLINDS OR DRAPES MAY STRANGLE CHILD.
- IF REFINISHING, USE A NON-TOXIC FINISH SPECIFIED FOR CHILDREN'S PRODUCTS.
- DO NOT LEAVE CHILD IN CRIB WITH SIDES LOWERED. BE SURE SIDE IS IN RAISED AND LOCKED POSITION WHENEVER CHILD IS IN CRIB. **(NOT APPLICABLE)**
- WHEN CHILD IS ABLE TO PULL TO STANDING POSITION, SET MATTRESS TO LOWEST POSITION AND REMOVE BUMPER PADS, LARGE TOYS AND OTHER OBJECTS THAT COULD SERVE AS STEPS FOR CLIMBING OUT.
- NEVER USE PLASTIC SHIPPING BAGS OR OTHER PLASTIC FILM AS MATTRESS COVERS BECAUSE THEY CAN CAUSE SUFFOCATION.
- DO NOT USE A WATER MATTRESS WITH THIS CRIB.
- THE MATTRESS USED WITH THIS CRIB MUST BE AT LEAST 27 1/4 INCHES BY 51 5/8 INCHES WITH A THICKNESS NOT EXCEEDING 6". THE GAP BETWEEN THE MATTRESS AND THE SIDES OF THE CRIB SHOULD NOT EXCEED 1 1/2 INCHES WHEN THE MATTRESS IS PUSHED INTO CORNER OF THE CRIB.
- REPLACE TEETHING RAIL IF DAMAGED OR LOOSE. **(NOT APPLICABLE)**
- USING A VAPORIZER PLACED NEAR FURNITURE WILL CAUSE WOOD TO SWELL AND FINISH TO PEEL.
- DO NOT STORE CRIB IN AREAS WHERE TEMPERATURES AND CONDITIONS ARE EXTREME, SUCH AS HOT DRY ATTICS OR COLD DAMP BASEMENTS. BOTH OF THESE EXTREME CONDITIONS MAY CAUSE WOOD TO CRACK AND GLUE JOINTS TO LOOSEN RESULTING IN STRUCTURAL FAILURE.
- A PERIODIC CHECK OF THE CRIB SHOULD BE MADE AND ALL SCREWS AND BOLTS RETIGHTENED, IF NECESSARY

WARNING: String can cause strangulation! Do Not Place items with a string around child's neck, such as hood strings or pacifier cords. Do Not suspend strings over crib or attach string to toys.