

ASSEMBLY INSTRUCTIONS

for Newport Crib




Carefully remove and lay out all parts, familiarize your shelf with all exhibits and diagrams to facilitate the assembly of your crib.


TOOLS REQUIRED:
allenwrench (supplied)

PARTS ENCLOSED IN CARTON


(1) Headboard




(1) Mattress spring



(1) Footboard



(2) Crib Sides



Left Side

Right Side

(2) Stabilizer bar




HARDWARE


(16) Black allenhead bolt 2"




(12) Brass allenhead bolt 5/8"




(8) Brass Wing Nut




(2) Dowel




(1) Allenwrench 3/16"



(4) Brass Nut



(4) Spring Support Brackets




THIS STEP REQUIRES:

- (1) HEADBOARD
- (2) CRIB SIDES

- (4) Black allenhead bolt 2"

FIG. 1



A. Insert (2) dowel into the bottom hole in the crib side

B. Insert (4) the 2" Black allenhead bolt through the top and bottom hole in the crib side and in to the threaded hole in the headboard. Hand tighten only.




STEP 2 " SPRING ASSEMBLY "

THIS STEP REQUIRES:

(8) Brass allenhead bolt 5/8 "


(8) Brass Wing nut

(4) Spring support brackets




MATTRESS SPRING

FIG. 2



A. See figure 3 for height adjustment. Insert the (8) 5/8" Brass allenhead bolt through the metal spring frame and support bracket and secure with Brass wing nut (FIG.2). Make sure the support brackets is positioned on the inside of the spring frame. Repeat all corners.

B. The three holes in the spring frame are for adjusting the height of the spring. Select the height position appropriate for the age of your child. (FIG. 3)



STEP 3 " SPRING INSTALLATION "

THIS STEP REQUIRES:

(4) Brass allenhead bolt 5/8 "

(4) Nut

(8) Black allenhead bolt 2"







FIG. 4



- A. Place the spring with the support brackets in position into the the stabilizer bar. Locate the threaded holes in the stabilizer bar. Insert (4) the 5/8" Brass allenhead bolt + Nut through the spring support brackets and into the threaded holes in the stabilizer bar. Secure with allenwrench.
- B. Place the spring and stabilizer bar assembly in position into the crib. Locate the threaded holes in the crib sides. Insert (8) the 2" Black allenhead bolt through crib sides and into stabilizer bars.

STEP 4 " ASSEMBLY OF FOOTBOARD "

THIS STEP REQUIRES:

(1) FOOTBOARD

(4) Black allenhead bolt 2"





FIG. 5



2" Black
allenhead bolt

2" Black
allenhead bolt

Insert (4) the 2" Black allenhead bolt through the top and bottom hole in the crib side and into the threaded hole in the footboard, tighten all allenhead bolts



WARNING!

- FAILURE TO FOLLOW THESE WARNINGS AND ASSEMBLY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.
- READ ALL INSTRUCTIONS BEFORE ASSEMBLING CRIB. **KEEP INSTRUCTIONS FOR FUTURE USE.**
- UPON COMPLETION OF ASSEMBLY BE SURE ALL SCREWS, BOLTS AND FASTENING DEVICES HAVE BEEN SECURELY TIGHTENED. A FREQUENT CHECK SHOULD BE MADE.
- BEFORE EACH USAGE OR ASSEMBLY, INSPECT CRIB FOR DAMAGED HARDWARE, LOOSE JOINTS, MISSING OR BROKEN PARTS AND SHARP EDGES. DO NOT USE THIS CRIB IF ANY PARTS ARE MISSING OR BROKEN. DO NOT SUBSTITUTE PARTS OF ANY KIND.
- WHEN THE CHILD IS ABLE TO CLIMB OUT OR REACHES THE HEIGHT OF 35 INCHES (90 CENTIMETERS), THE CRIB SHALL NO LONGER BE USED. THE CHILD SHOULD BE PLACED IN A YOUTH BED OR TODDLER BED.
- DO NOT PLACE CRIB NEAR WINDOW WHERE CORDS FROM BLINDS OR DRAPES MAY STRANGLE A CHILD.
- IF REFINISHING, USE A NON-TOXIC FINISH SPECIFIED FOR CHILDREN'S PRODUCTS.
- WHEN CHILD IS ABLE TO PULL TO STANDING POSITION, SET MATTRESS TO LOWEST POSITION AND REMOVE BUMPER PADS, LARGE TOYS AND OTHER OBJECTS THAT COULD SERVE AS STEPS FOR CLIMBING OUT.
- NEVER USE PLASTIC SHIPPING BAGS OR ANY PLASTIC FILM AS MATTRESS COVERS, BECAUSE THEY CAN CAUSE SUFFOCATION.
- ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 27-1/4 INCHES (69 CENTIMETERS) BY 51-5/8 INCHES (131 CENTIMETERS), WITH A THICKNESS NOT EXCEEDING 6 INCHES (15 CENTIMETERS), THE DIMENSIONS OF THE MATTRESS SHALL BE TAKEN FROM SEAM TO SEAM OR EDGE TO EDGE WHERE APPROPRIATE.
- DO NOT USE A WATER MATTRESS WITH THIS CRIB.
- WARNING. STRINGS CAUSE STRANGULATION! DO NOT PLACE ITEMS WITH A STRING AROUND A CHILD'S NECK, SUCH AS HOOD STRINGS OR PACIFIER CORDS. DO NOT SUSPEND STRING OVER A CRIB OR ATTACH STRINGS TO TOYS.
- WHEN STORING CRIB USE CAUTION AS EXTREME CHANGES IN TEMPERATURE OR HUMIDITY CAN COMPROMISE THE CRIB MAKING IT EXTREMELY DANGEROUS TO YOUR CHILD.
- USE CAUTION WHEN A VAPORIZER OR HUMIDIFIER IS IN USE. ALWAYS AIM VAPOR AWAY FROM THE CRIB AS WELL AS ANY OTHER WOODEN FURNITURE. PROLONGED PERIODS OF HUMIDITY IN STORAGE AS WELL AS THE HOME CAN COMPROMISE THE CRIB.
- AVOID USING VAPORIZERS AND HUMIDIFIERS FOR PROLONGED PERIODS OF TIME.