



CRIB ASSEMBLY INSTRUCTIONS

ALL RAGAZZI CRIBS ARE FULL SIZE CRIBS WHICH MEET OR EXCEED THE REQUIREMENTS OF THE **AMERICAN CONSUMER PRODUCT SAFETY COMMISSION**.

RAGAZZI CRIBS ARE TESTED AT AN INDEPENDENT LABORATORY FOR COMPLIANCE TO THE REQUIREMENTS OF MANDATORY STANDARDS (CODE OF FEDERAL REGULATIONS - PART 1508 - REQUIREMENTS FOR FULL-SIZE BABY CRIBS).

CAMACUNA INSTRUCCIONES PARA EL MONTAJE

TODAS LAS CUNAS RAGAZZI SON DE TAMAÑO ADULTO Y ESTÁN EN CONFORMIDAD CON LOS REQUISITOS DE LA **AMERICAN CONSUMER PRODUCT SAFETY COMISIÓN** O LOS SUPERAN.

LAS CUNAS RAGAZZI ESTÁN INSPECCIONADAS POR UN LABORATORIO INDEPENDIENTE PARA ASEGURAR SU CONFORMIDAD CON LAS NORMAS OBLIGATORIAS (CODE OF FEDERAL REGULATIONS PART 1508 - REQUIREMENTS FOR FULLSIZE BABY CRIBS)

WARNING

- FAILURE TO FOLLOW THESE WARNINGS AND ASSEMBLY INSTRUCTIONS CAN RESULT IN SERIOUS INJURY TO THE CHILD.
- READ ALL INSTRUCTIONS BEFORE ASSEMBLING CRIB.
- **KEEP INSTRUCTIONS FOR FUTURE USE.**
- BEFORE EACH USAGE OR ASSEMBLY, INSPECT CRIB FOR DAMAGED HARDWARE, LOOSE JOINTS, MISSING PARTS OR SHARP EDGES.
- **DO NOT** USE CRIB IF ANY PARTS ARE MISSING OR BROKEN. ASK YOUR DEALER OR WRITE TO RAGAZZI FOR REPLACEMENT PARTS AND INSTRUCTIONAL LITERATURE IF NEEDED.
- **DO NOT** SUBSTITUTE PARTS.
- **DO NOT** USE THIS CRIB FOR A CHILD WHO IS ABLE TO CLIMB OUT UNAIDED OR WHO IS TALLER THAN 35 INCHES (90 CM).
- **DO NOT** PLACE CORDS, STRAPS OR SIMILAR ITEMS THAT COULD BECOME WOUND AROUND A CHILD'S NECK IN OR NEAR THIS CRIB.
- IF REFINISHING, USE NON-TOXIC FINISH SPECIFIED FOR CHILDREN'S PRODUCTS.
- **DO NOT** LEAVE CHILD IN CRIB WITH SIDE LOWERED. BE SURE SIDE IS IN RAISED AND LOCKED POSITION WHENEVER CHILD IS IN CRIB.
- WHEN CHILD IS ABLE TO STAND IN CRIB, SET MATTRESS TO LOWEST POSITION AND REMOVE BUMPER PADS, LARGE TOYS AND OTHER OBJECTS THAT COULD SERVE AS STEPS FOR CLIMBING OUT.
- NEVER USE PLASTIC SHIPPING BAGS OR OTHER PLASTIC FILM AS MATTRESS COVERS BECAUSE THEY CAN CAUSE SUFFOCATION.
- **DO NOT** USE A WATER MATTRESS WITH THIS CRIB.
- REPLACE TEETHING RAIL IF DAMAGED OR LOOSE (IF APPLICABLE).
- **CAUTION:** ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 27-1/4 INCHES BY 51-3/8 INCHES WITH A THICKNESS NOT EXCEEDING 6 INCHES.

IMPORTANT

PARENTS SHOULD ENSURE A SAFE ENVIRONMENT FOR THE CHILD BY CHECKING REGULARLY, BEFORE PLACING THE CHILD IN THE CRIB, THAT EVERY COMPONENT IS PROPERLY AND SECURELY IN PLACE.

ADVERTENCIA


- EL NO CONFORMARSE CON LAS INSTRUCCIONES DE MONTAJE Y LAS ADVERTENCIAS CONTENIDAS EN ESTE DOCUMENTO PODRÍA PROVOCAR HERIDAS GRAVES EN EL NIÑO.
- SÍRVASE LEER ATENTAMENTE TODAS LAS INSTRUCCIONES ANTES DE EMPEZAR A ENSAMBLAR LA CUNA.
- **GUARDE LAS INSTRUCCIONES PARA UTILIZACIÓN ULTERIOR**
- ANTES DE ENSAMBLAR O UTILIZAR, VERIFIQUE QUE LA CUNA NO TENGA PIEZAS DAÑADAS, DESPRENDIDAS, FLOJAS, O CON BORDES AFILADOS., NI QUE LE FALTE NINGUNA PIEZA.
- **NO** UTILICE LA CUNA SI ESTÁ DAÑADA O SI LE FALTAN PIEZAS. PIDA LAS PIEZAS DE RECAMBIO Y LAS INSTRUCCIONES DE INSTALACIÓN A SU DETALLISTA O ESCRIBA A RAGAZZI SI ES NECESARIO.
- **NO** SUSTITUYA UNAS PIEZAS POR OTRAS.
- **NO** UTILICE ESTA CUNA SI EL NIÑO PUEDE SALIRSE DE ELLA SIN AYUDA O SI MIDE MÁS DE 35 PULGADAS (90 CM).
- **NO** PONGA CUERDA, CORREAS NI OTROS ARTÍCULOS SIMILARES EN LA CUNA O CERCA DE ELLA PUESTO QUE SE PUEDEN ENROLLAR ALREDEDOR DEL CUELLO DEL NIÑO.
- SI DESEA VOLVER A PINTAR LA CUNA, UTILICE PINTURA NO TÓXICA ESPECIALMENTE CONCEBIDA PARA ARTÍCULOS INFANTILES.
- **NO** DEJE NUNCA AL NIÑO EN LA CUNA CON EL PANEL BAJADO, ÉSTE DEBE DE ESTAR SIEMPRE CERRADO CUANDO EL NIÑO SE ENCUENTRA EN LA CUNA.
- CUANDO EL NIÑO EMPIEZA A PARARSE EN LA CUNA, BAJE EL COLCHÓN A LA POSICIÓN MÁS BAJA YQuite EL BORDE PROTECTOR, LOS JUGUETES GRANDES Y CUALQUIER OTRO OBJETO SOBRE EL CUAL EL NIÑO PODRÍA SUBIRSE Y SALIRSE DE LA CUNA.
- NUNCA UTILIZAR BOLSAS DE PLÁSTICO U OTRAS CUBIERTAS PLÁSTICAS PARA FORRAR EL COLCHÓN, PORQUE PODRÍAN PROVOCAR QUE EL NIÑO SE ASFIXIE.
- **NO** UTILIZAR UN COLCHÓN DE AGUA EN ESTA CUNA.
- EN SU CASO, CAMBIAR EL PROTECTOR DE DENTCIÓN QUE CUBRE EL TRAVESAÑO SI ESTÁ DAÑADO O SUELTO.
- **AVISO :** EN ESTA CUNA, DEBE USARSE UN COLCHÓN DE AL MENOS 27-1/4 PULGADAS SOBRE 51-3/8 PULGADAS CUYO ANCHO NO DEBE SER DE MÁS DE 6 PULGADAS.

IMPORTANTE


LOS PADRES DEBEN SIEMPRE CERCIORARSE DE LA SEGURIDAD DE LA CUNA VERIFICANDO REGULARMENTE TODOS SUS COMPONENTES ANTES DE INSTALAR AL NIÑO EN ELLA.

CRIB ASSEMBLY INSTRUCTIONS • CUNA - INSTRUCCIONES DE ENSAMBLADO


CONTENTS OF
HARDWARE BAG
LA BOLSA DE
HERRAJES CONTIENE:




I




J




K



N



O



P




Q




R




S



T



W




SMALL ALLEN KEY
LLAVE HEXAGONAL PEQUEÑA (ALLEN)




LARGE ALLEN KEY
LLAVE HEXAGONAL GRANDE (ALLEN)

FACTORY
INSTALLED
HARDWARE
PIEZAS DE
HERRAJE
INSTALADAS
EN LA FÁBRICA



V



U

PARTS LIST AND DESCRIPTION: LISTA DE PIEZAS Y DESCRIPCIÓN :

1	HEADBOARD CABECERA	A
1	FIXED GATE BARANDA FIJA	B
2	STABILIZER BARS BARRAS ESTABILIZADORAS	C Y D
2	FOOTBOARD PIECERA	E
1	METAL MATTRESS FRAME SOMIER METÁLICO	F
4	ADJUSTMENT ARMS BRAZOS REGULADORES	G (Factory installed) (Instalados en la fábrica)
1	DROP SIDE GATE BARANDA ABATIBLE	H
2	LOWER GUIDE PINS ESPIGAS DE GUÍA INFERIORES	I
2	FLAT HEAD SCREWS TORNILLOS DE CABEZA PLANA	J (For upper guides) (Para guías superiores)
2	UPPER GUIDES GUÍAS SUPERIORES	K
4	INSERT NUTS TUERCAS DE INSERCIÓN	N (For stabilizer bars) (Para barras estabilizadoras)
4	LONG FLAT HEAD LAG BOLTS TIRAFONDOS DE LARGOS CABEZA PLANA	O (For stabilizer bars) (Para barras estabilizadoras)
6	SHORT FLAT HEAD LAG BOLTS TIRAFONDOS CORTOS DE CABEZA PLANA	P (For headboard) (Para panel lateral)
4	ROUND HEAD BOLTS PERNOS DE CABEZA REDONDA	Q (For metal mattress frame) (Para el somier metálico)
4	WASHERS ARANDELAS	R (For metal mattress frame) (Para el somier metálico)
4	NUTS TUERCAS	S (For metal mattress frame) (Para el somier metálico)
4	FLAT HEAD SCREWS ALLEN TORNILLOS DE CABEZA PLANA HEXAGONAL	T (For attaching mattress frame to stabilizer bars) (Para sujetar el somier a las barras estabilizadoras)
2	UPPER TRACK FOR DROP SIDE GATE TRAVESAÑOS SUPERIORES PARA PANEL ABATIBLE	U (Factory installed) (Instalados en la fábrica)
2	LOWER TRACK FOR DROP SIDE GATE TRAVESAÑOS INFERIORES PARA PANEL ABATIBLE	V (Factory installed) (Instalados en la fábrica)
4	CASTERS RUEDAS	W
1	SMALL ALLEN KEY LLAVE HEXAGONAL PEQUEÑA (ALLEN)	
1	LARGE ALLEN KEY LLAVE HEXAGONAL GRANDE (ALLEN)	

ADDITIONAL TOOLS REQUIRED
HERRAMIENTAS ADICIONALES NECESARIAS:
A PHILLIPS SCREWDRIVER AND A WRENCH.
1 DESTORNILLADOR PHILIPS Y UN JEUGO DE LLAVES

YOU MIGHT WANT TO ASK A FRIEND TO HELP YOU WITH THE ASSEMBLY OF THE CRIB

PREPARATION: Check the crib parts against the PARTS LIST, including the quantities in the hardware bag.

STEP 1 - Place the headboard (A) and the footboard (E) flat on the floor so that the inside surface is facing up, and the top rail is away from you. Make sure to protect the headboard and footboard by laying them on a carpet or on a blanket.

STEP 2 - Screw the lower guide pin (I) in the lower hole of the headboard (A) as shown in the diagram. Repeat same step for footboard (E). Use a Phillips screwdriver to well tighten the pins. If the pins (I) are not securely tightened, they might come loose, and interfere with the mechanism of the drop side.

STEP 3 - Insert the flat head screw (J) into the upper guide (K), and screw it into the upper hole on headboard (A), using the smaller allen wrench to tighten the screw firmly. Make sure not to over tighten. If the screw is over tightened, the space between the outer disc of guide (K) and the inner disc that is in contact with the headboard (A) will be compressed. This compression may prevent the guide (K) from sliding inside the upper track (U) found in each end of the drop-side (H).

Repeat STEP 3 for the footboard (E).

STEP 4 - If you purchased a drawer for your crib, you should install the drawer slides at this stage. Please refer to the instructions included in your crib drawer box.

STEP 5 - INSTALLATION OF THE STABILIZER BARS (C) AND (D)

Align the factory-installed dowel in the end of the stabilizer bar (C) with the top hole in headboard (A). Make sure that the dowel is nearest the top side of the bar and that the predrilled holes along the length of the stabilizer bar are facing inward.

Push the long flat head lag bolt (O) through the bottom hole on the outside of headboard (A) and into the end of stabilizer bar (C). Do not push long lag bolt (O) all the way in until you have inserted the insert nut (N) in the predrilled hole on the inside of the stabilizer bar (C). Make sure that the threaded hole in the side of the nut (N) is aligned with hole in the end of stabilizer bar (C). The long lag bolt (O) may now be pushed in and secured with the larger Allen key. Do not over tighten bolts at this time.

Repeat STEP 5 for stabilizer bar (D). You can now attach both stabilizer bars (C) and (D) to footboard (E).

STEP 6 - INSTALLATION OF THE METAL MATTRESS FRAME (F)

Select your desired mattress level and the appropriate holes along the length of the metal mattress frame (F) (see diagram). It is important to select the same adjustment level

LE ACONSEJAMOS QUE PIDA AYUDA PARA ARMAR LA CUNA

PRÉPARACIÓN - Verifique que todas las piezas de la cuna corresponden, en descripción y cantidad, a la lista de piezas incluidas en la bolsa de herrajes.

ETAPA 1 - Coloque la cabecera (A) y la piecera (E) sobre el suelo, la superficie interior cara arriba y el travesaño superior alejado de usted. Para no dañar la cabecera ni la piecera póngalas sobre una alfombra o una cobija, previamente colocada sobre el suelo.

ETAPA 2 - Atornille la espiga guía inferior (I) dentro del hueco inferior de la cabecera (A), tal como ilustrado. Repita la misma operación con la piecera (E). Utilice un destornillador Phillips para apretar bien las espigas. Al no estar bien apretadas, éstas podrían impedir el buen funcionamiento de la baranda abatible.

ETAPA 3 - Introduzca el tornillo de cabeza plana (J) en la guía superior (K) y con la pequeña llave hexagonal atorníllelo bien dentro del hueco superior ubicado sobre la cabecera (A). No lo apriete demasiado para no comprimir el espacio entre el disco externo de la guía (K) y el disco interno que está en contacto con la cabecera (A), ya que tal compresión podría impedir que la guía (K) se deslice en el interior del travesaño superior (U) que se encuentra en cada extremidad de la baranda abatible (H).

Repita la etapa 3 con la piecera (E)

ETAPA 4 - Si compró un cajón para la cuna, instale las guías de deslizamiento ahora, siguiendo las instrucciones incluidas en el embalaje del cajón.

ETAPA 5 - INSTALACIÓN DE LAS BARRAS ESTABILIZADORAS (C y D)

Alinee la espiga instalada en la fábrica que se encuentra en la punta de la barra estabilizadora (C) con el hueco superior de la cabecera (A). Cerciórese de que la espiga queda cerca del lado superior de la barra y que los huecos preperforados que se encuentran a lo largo de la barra estabilizadora miran hacia el interior. Empuje el tirafondo largo de cabeza plana (O) dentro del hueco inferior ubicado en el exterior de la cabecera (A) y dentro de la punta de la barra estabilizadora (C). No empuje el tirafondo hasta el fondo antes de haber colocado la tuerca de inserción (N) en el hueco preperforado ubicado en la parte interior de la barra estabilizadora (C). Asegúrese de que el agujero roscado en el lado de la tuerca (N) está alineado con el hueco ubicado en la punta de la barra estabilizadora (C). Puede ahora empujar el tirafondo largo (O) dentro de la tuerca y cerrarlo con la llave hexagonal grande. No apriete todavía del todo las tuercas. Repita la misma operación con la otra barra estabilizadora (D). Una vez esto hecho, puede ya fijar las dos barras estabilizadoras (C y D) a la piecera (E).

hole in the metal mattress frame (F) for each adjustment arm (G). This will result in a level or parallel mattress. Secure one end of the long adjustment arm (G) to the metal frame unit (F) with a round head bolt (Q), a washer (R) and a nut (S) (see diagram). Make sure that the tag on the mattress frame is facing up. Repeat this step for the three remaining adjustment arms (G). Use the Phillips screwdriver and a wrench to firmly tighten all four bolts and nuts.

The mattress frame is now ready to be installed. Align the holes in the end of the adjustment arms (G) with the holes on the inside of both stabilizer bars (C) and (D). Secure it tightly with the flat head Allen screw (T) using the large Allen key.

STEP 7 - INSTALLATION OF THE FIXED SIDE GATE (B)

Align the fixed side gate (B) with headboard (A), ensuring that the rounded top rail of the gate is located at the top. Use the short flat head lag bolt (P) to secure the fixed side gate (B) to headboard (A). Make sure that the holes are in line and start by screwing the short flat head lag bolt (P) with your hands, in order not to force and damage the thread of the pre-installed inserts in the headboard (A). If not properly aligned, the correct assembly of the crib may be compromised. Once the short flat head lag bolt (P) is correctly in place, tighten with the larger Allen key.

Repeat STEP 7 for footboard (E).

STEP 8 - INSTALLATION OF THE DROP SIDE GATE (H)

Part A - Loosen the long flat head lag bolt (O), located at each end of the stabilizer bar (D) on the outside of the headboard (A) and footboard (E). Loosen only the bolts of the stabilizer bar (D). These flat head lag bolts are to be loosened but not removed. They should remain sufficiently engaged with insert nut (N). This step is required to provide the necessary space between the drop side gate (H) and the lower guides pins (I) that were installed in STEP 2, and to prevent scratching of your crib.

You are now ready to install the drop side gate (H).

Part B - Hold the drop side gate (H) out in front of you. Make sure that the groove at the bottom of the lower track (V) is facing inward. The removable orange dot should be on the outside of the crib. The lower horizontal rail of the drop gate (H) should be touching your leg below the knee and the top rail of the drop gate (H) should be tilted slightly away from you. Making sure that the headboard (A) and the footboard (E) have been pulled away from the stabilizer bar (D), carefully align the upper track (U) with the upper guide (K) and slide them together. It is important to keep the end rails of drop side gate (H) parallel with both the headboard (A) and the footboard (E) to avoid damaging the hardware or scratching the wood finish.

With both upper guides (K) inside the upper tracks (U) and approximately three inches (3") down from the top of track (U), pivot lower rail

ETAPA 6 - INSTALACIÓN DEL SOMIER METÁLICO (F)

Escoja la altura a la cual desea colocar el colchón y los huecos correspondientes a ésta, ubicados sobre el largo del somier metálico (F), tal como se indica en la ilustración. Es importante escoger el mismo nivel de ajuste sobre el somier (F) para cada uno de los brazos reguladores (G) de manera que el colchón quede nivelado y paralelo. Fije una de las extremidades del brazo regulador largo (G) al somier (F) con un perno de cabeza redonda (Q), una arandela y una tuerca (S) tal como se indica en la ilustración. Asegúrese de que la etiqueta sobre el somier queda hacia arriba. Repita esta etapa con los otros tres brazos reguladores (G). Utilice un desatornillador Phillips y una llave para apretar bien los cuatro pernos y tuercas.

Ahora ya puede instalar el somier. Alinee los huecos ubicados en la punta de los brazos reguladores (G) con los huecos ubicados en la parte interior de las dos barras estabilizadoras (C y D). Con la llave hexagonal grande apriete bien los tornillos de cabeza plana hexagonal (T).

ETAPA 7 - INSTALACIÓN DE LA BARANDA FIJA (B)

Alinee la baranda fija (B) con la cabecera (A). Cerciórese de que el travesaño superior redondeado se encuentra arriba. Sujete la baranda fija (B) a la cabecera (A) mediante el tirafondo corte de cabeza plana (P), asegurándose de que los huecos quedan bien alineados y atornille el tirafondo corto de cabeza plana (P) a mano para no forzar o dañar el roscado de los insertos preinstalados en la cabecera (A). Si el alineamiento no se hace bien, la cuna no quedará solidamente armada. Una vez el tirafondo corto de cabeza redonda (P) correctamente colocado, atornillelo con la llave hexagonal grande. Repita la etapa 7 para fijar la baranda a la piecera (E).

ETAPA 8 - INSTALACIÓN DE LA BARANDA ABATIBLE (H)

Parte A - Desatornille el tirafondo largo de cabeza plana (O), situado en cada punta de la barra estabilizadora (D) al exterior de la cabecera (A) y de la piecera (E). Desatornille solamente los pernos de la barra estabilizadora sin sacarlos del agujero y déjelos suficientemente metidos dentro de la tuerca de inserción (N). Es importante seguir fielmente esta etapa para dejar el espacio necesario entre la baranda abatible (H) y las espigas de guía inferiores (I) instaladas en la etapa 2. De esta manera, se evitará rayar la cuna. Ahora ya puede instalar la baranda abatible (H).

Parte B - Sostenga la baranda abatible (H) delante de usted, asegurándose de que la ranura en la parte baja del la guía inferior (V) mira hacia el interior. El punto anaranjado amovible debe quedar sobre la faz exterior de la cuna. El travesaño horizontal inferior ubicado sobre la baranda móvil (H) debe tocar su pierna por debajo de la rodilla mientras que el travesaño exterior debe estar ligeramente inclinado en dirección opuesta a usted. Después de cerciorarse de que la cabecera (A) y la piecera (E) están apartadas de la barra estabilizadora (D), alinee cuidadosamente el travesaño superior (U) con la guía superior (K) y hágalos

of drop side gate (H) toward the lower guide pin (I), until it almost touches it. Then align the lower guide pin (I) with the groove in the lower track (V) and push together. Make sure that pin (I) is inside track (V). If you need more space between the drop side gate (H) and the track (V) you may gently pull inside track (V) away from the drop side gate (H) and / or loosen long flat head lag bolt (O). Be careful not to disengage long flat head lag bolt (O) from insert nut (N). Do this for both the headboard (A) and the footboard (E).

Part C - Now that all (4) four guides and tracks are properly installed it is time to re-tighten both long flat head lag bolts (O), located on the outside of headboard (A) and footboard (E), at both ends of the stabilizer bars (C) and (D). When re-tightening, make sure the dowels in both ends of stabilizer bar (D) are aligned with its guide hole in headboard (A) and footboard (E), to ensure a proper and tight connection.

RECHECK ALL OF THE BOLTS AND SCREWS TO MAKE SURE THAT THEY ARE TIGHT.

STEP 9 - TESTING THE TRAVEL OF SIDE DROP GATE (H)

With the drop side gate (H) in its lower position, grasp the top rail near the center and pull all the way up until you hear a click. This is the sound of the guide pin clicking into the locked position. Push gently down on both the left and the right ends of the top rail of the drop side gate (H) to make sure that both ends have locked into place. If it doesn't lock properly, pull the gate toward you holding it from the center of the lower side.

To lower the drop side gate (H) grasp the top rail near the center and pull up while pushing in on the lower rail of the drop side gate (H) with your lower leg or knee. The side drop gate (H) will now lower.

STEP 10 - INSERTION OF CASTERS (W)

Slip the four casters (W) into inserts located inside holes of headboard (A) and footboard (E). Press firmly to lock in place.

REMEMBER TO CHECK ALL THE SCREWS AND BOLTS REGULARLY, AND TIGHTEN THEM IF NEEDED. MAKE SURE THAT BOTH ENDS OF THE DROP SIDE GATE ARE LOCKED IN THE UPPER POSITION ANYTIME THAT THE CHILD IS IN THE CRIB. THE DROP SIDE GATE SHOULD BE LOWERED ONLY WHEN YOU NEED TO ATTEND TO THE CHILD.

deslizarse juntos. Es importante que los travesaños de la extremidad de la baranda abatible(H) queden paralelos a la cabecera (A) y la piecera (E) para evitar que se dañe el herraje o que se raye el acabado de la madera. Con las dos guías superiores (K) colocadas en el interior de los travesaños superiores (U) a unas tres pulgadas (7cm) de la parte de arriba del travesaño (U), haga girar el travesaño inferior de la baranda abatible (H) hacia la espiga de guía inferior (I) hasta que la toque. Luego, alinee la espiga de guía interior (I) con la ranura del travesaño interior (V) y empuje las dos partes juntas. Cerciórese de que la espiga (I) quedó bien en el interior del travesaño (V). Si necesita más espacio entre la baranda abatible (H) y el travesaño (V), puede jalar suavemente el travesaño interior (V) del lado opuesto a la baranda (H) y/o aflojar un poco el tirafondo de cabeza plana (O). Tenga cuidado de no sacar el tirafondo (O) de la tuerca de inserción (N). Haga lo mismo con la cabecera (A) y la piecera (E).

Parte C - Una vez que se instalaron correctamente los cuatro (4) travesaños y guías, atornille bien los dos tirafondos de cabeza plana (O), situados al exterior de la cabecera (A) y de la piecera (E), a las dos extremidades de las barras estabilizadoras (C y D). Mientras que atornilla, asegúrese que las espigas en las dos extremidades de la barra estabilizadora (D) están en línea con el agujero de guía ubicado en la cabecera (A) y la piecera (E) para asegurar un empalme sólido.

ASEGÚRESE DE QUE TODOS LOS PERNOS Y TORNILLOS QUEDARON BIEN APRETADOS

ETAPA 9 - CERCÍÓRESE DE QUE LA BARANDA ABATIBLE (H) CORRE BIEN

Coloque la baranda abatible (H) en su posición más baja, agarre el travesaño superior por el centro y jale la baranda hacia arriba hasta que se escuche un chasquido, es decir el sonido que hace la espiga de guía al engranarse en posición de bloqueo. Empuje suavemente sobre las dos extremidades del travesaño superior del panel (H) para asegurarse de que los dos lados están bien engranados y bloqueados. Si no se engrana bien, jale la baranda hacia usted agarrándola por el centro del lado inferior. Para bajar la baranda (H), agarre el travesaño superior cerca del centro y jálelo hacia arriba a la vez que empuja el travesaño inferior con el bajo de la pierna o la rodilla. El panel (H) debería ahora bajarse.

ETAPA 10 - INSTALACIÓN DE LAS RUEDAS (W)

Introduzca las cuatro (4) ruedas (W) dentro de los huecos previstos para ello en la cabecera (A) y la piecera (E). Empuje firmemente para bloquearlas en su lugar.

NO OLVIDE VERIFICAR REGULARMENTE TODOS LOS PERNOS Y TORNILLOS PARA ASEGURARSE QUE ESTÉN BIEN APRETADOS. VUELVA A APRETARLOS CUANDO SEA NECESARIO. ASEGÚRESE TAMBIÉN DE QUE MIENTRAS ESTÉ EL NIÑO EN LA CUNA LOS DOS EXTREMOS DE LA BARANDA ABATIBLE ESTÉN SIEMPRE BLOQUEADOS EN POSICIÓN ELEVADA. ESTA BARANDA DEBE BAJARSE SOLO CUANDO ESTÁ USTED OCUPÁNDOSE DEL NIÑO.

